

Charvel Desolation™ Series

JC2931310503	293-1310-503	Desolation™ DX-1 ST, Rosewood Fretboard, Black	€	701,00
JC2931310550	293-1310-550	Desolation™ DX-1 ST, Rosewood Fretboard, Flat Black	€	701,00
JC2931310596	293-1310-596	Desolation™ DX-1 ST, Rosewood Fretboard, Snow White	€	701,00
JC2931310515	293-1310-515	Desolation™ DX-1 ST, Rosewood Fretboard, Cherry Sunburst	€	761,50
JC2931310557	293-1310-557	Desolation™ DX-1 ST, Rosewood Fretboard, Transparent Black	€	761,50
JC2931310586	293-1310-586	Desolation™ DX-1 ST, Rosewood Fretboard, Transparent Blue Smear	€	761,50
JC2931310590	293-1310-590	Desolation™ DX-1 ST, Rosewood Fretboard, Transparent Red	€	761,50
JC2931311550	293-1311-550	Desolation™ DX-1 FR, Rosewood Fretboard, Flat Black	€	822,00
JC2931311596	293-1311-596	Desolation™ DX-1 FR, Rosewood Fretboard, Snow White	€	822,00
JC2931311515	293-1311-515	Desolation™ DX-1 FR, Rosewood Fretboard, Cherry Sunburst	€	894,50
JC2931311557	293-1311-557	Desolation™ DX-1 FR, Rosewood Fretboard, Transparent Black	€	894,50
JC2931311586	293-1311-586	Desolation™ DX-1 FR, Rosewood Fretboard, Transparent Blue Smear	€	894,50
JC2931311590	293-1311-590	Desolation™ DX-1 FR, Rosewood Fretboard, Transparent Red	€	894,50
JC2931410503	293-1410-503	Desolation™ DST-1 ST, Rosewood Fretboard, Black	€	701,00
JC2931410557	293-1410-557	Desolation™ DST-1 ST, Rosewood Fretboard, Transparent Black	€	761,50
JC2931410586	293-1410-586	Desolation™ DST-1 ST, Rosewood Fretboard, Transparent Blue Smear	€	761,50
JC2931410590	293-1410-590	Desolation™ DST-1 ST, Rosewood Fretboard, Transparent Red	€	761,50
JC2931410596	293-1410-596	Desolation™ DST-1 ST, Rosewood Fretboard, Snow White	€	701,00
JC2931411503	293-1411-503	Desolation™ DST-1 FR, Rosewood Fretboard, Black	€	822,00
JC2931411557	293-1411-557	Desolation™ DST-1 FR, Rosewood Fretboard, Transparent Black	€	894,50
JC2931411586	293-1411-586	Desolation™ DST-1 FR, Rosewood Fretboard, Transparent Blue Smear	€	894,50
JC2931411590	293-1411-590	Desolation™ DST-1 FR, Rosewood Fretboard, Transparent Red	€	894,50
JC2931411596	293-1411-596	Desolation™ DST-1 FR, Rosewood Fretboard, Snow White	€	822,00
JC2931430503	293-1430-503	Desolation™ DST-3 FR 1H, Rosewood Fretboard, Black	€	422,50
JC2931430596	293-1430-596	Desolation™ DST-3 FR 1H, Rosewood Fretboard, Snow White	€	422,50
JC2931310503	293-1310-503	Desolation™ DX-1 ST, Rosewood Fretboard, Black	€	701,00
JC2931310550	293-1310-550	Desolation™ DX-1 ST, Rosewood Fretboard, Flat Black	€	701,00
JC2931310596	293-1310-596	Desolation™ DX-1 ST, Rosewood Fretboard, Snow White	€	701,00
JC2931310515	293-1310-515	Desolation™ DX-1 ST, Rosewood Fretboard, Cherry Sunburst	€	761,50
JC2931310557	293-1310-557	Desolation™ DX-1 ST, Rosewood Fretboard, Transparent Black	€	761,50
JC2931310586	293-1310-586	Desolation™ DX-1 ST, Rosewood Fretboard, Transparent Blue Smear	€	761,50